



why! W670SZQ1 La Batterie

Before any intervention, it is recommended to remove the battery



Written By: Felice Suglia



INTRODUCTION

Before any intervention, it is recommended to remove the battery

Step 1 — Battery



- Unlock the left latch.
- Unlock the right latch.
- Remove the battery while maintaining the unlocked latch.

Pour réassembler votre appareil, suivez les instructions dans l'ordre inverse.

This document was last generated on 2017-07-12 10:54:58 AM.